

MOUNTING W/CAM'S

1. Drape chain over the tire with cam's facing out and open.
2. Confirm that all side rail and hooks are straight.
3. Tuck both ends under the tire.
4. Drive forward about 2-3 feet.
5. Pull the inside side rail chain tight, pull the extra links back before connecting inside hook.
6. Pull chain tight to the front of the tire, make sure the extra links are pull back on the side rail, then hook or use lever by sliding lever through the link and rotating lever back to the siderail retainer link.
7. Begin turning cams 180° until chains are snug. Drive a short distance 10-20' and then test if still snug. If not – close more cams. If all cams are closed and chains are still loose – open all cams and reconnect hooks (inside and outside) into a tighter position and repeat steps 5 & 6.
8. Chains **MUST** be snug before driving.